

## NOTES:

- 1. USE 5:1 (AGGREGATE: CEMENT) MIX FOR CONCRETE EDGE.
- 2. RECOMMENDED FOR ONLY NON-FREEZE THAW AREAS OVER WELL DRAINING SOILS.
- 3. CONSTRUCTION OF THIS DETAIL CAN BE USED ONLY ON RESIDENTIAL DRIVEWAYS IN NON-FREEZE THAW AREAS.
- 4. THICKNESS OF AGGREGATE BASE WILL VARY WITH SUBGRADE CONDITIONS AND CLIMATE. COLDER CLIMATES MAY REQUIRE THICKER BASES.



## PATIO/WALK/RESIDENTIAL DRIVEWAY W/ TROWELED CONCRETE EDGE RESTRAINT

DRAWING NO.

ICPI-05

SCALE

NO SCALE